



Note : Flow / Return can not be reserved.  
If heating element is installed, push the diverter with a screwdriver.



- |    |  |                  |       |
|----|--|------------------|-------|
| 1- |  | Allen Key        | 1 pcs |
| 2- |  | Bracket          | 4 pcs |
| 3- |  | Short Pillar Nut | 4 pcs |
| 4- |  | Grub Screw       | 8 pcs |
| 5- |  | Wall Plug        | 4 pcs |
| 6- |  | Screw, dia 6mm.  | 4 pcs |
| 7- |  | Air Vent         | 1 pcs |
| 8- |  | Blanking Plug    | 1 pcs |

### Wall Mounting Instructions:

- 1- According to the relative wall connection axis (L) & (S) drill 4 Nr holes 10 mm.Ø x 50 mm. depth.
- 2- Insert wall plugs (5) into the drilled holes.
- 3- Screw the brackets (2) with the screws (6) into the wall plugs (5).
- 4- The Short Pillar Nuts (3) are screwed into the collectors at the back of the radiator as shown.
- 5- Offer up the radiator and insert the short pillar nuts (3) into the brackets (2).
- 6- Using the allen key (1) provided, retain the short pillar nuts (3) into the brackets (2) with the grub screws (4).

Not suitable for use with direct hot water systems. Not suitable for gravity circulation.

Product Code	Width	Height	Conn. Centers	Assembly Axis		No. Of Tubes
	W	H	C	S	L	
FORS0760-08	515	760	520	390	520	8
FORS0760-10	645	760	520	520	520	10
FORS0760-12	775	760	520	650	520	12

\*All measurements are in millimeters  
This publication is issued subject to alteration or withdrawal without notice

